

## Loop trunk adapter (53518)

- ✓ Connects paging system to loop star start trunk
- ✓ Dedicates trunk for paging only
- ✓ Legend compatible