

Norstar 0x16 Fiber Station Module NTBB41

- ✓ To add additional station ports to the Modular ICS core, Fiber Station Modules may be connected by a fiber cable.
 - ✓ Each Fiber Station Module expands the core Modular ICS system by up to 16 station ports.
- It has One Male a 50-pin amphenol connection is used as the interface for the stations.

