



# TECHNICAL Practice


**TELECOM SOLUTIONS FOR THE 21ST CENTURY**

**LDB-2**

**Ring/Loop  
Detector**

January 6, 2009

## **Provide a Contact Closure on Ringing or Off-Hook**



The **LDB-2** Ring/Loop Detector monitors an analog phone line for ringing or an in-use condition. A built-in relay can be activated when either of these conditions are detected. This is ideal for monitoring line status or for providing a visual indication of such.

When monitoring for ring, an internal pot can be adjusted to allow the relay closure to stay on steady, or follow standard ring cadence.

The **LDB-2** comes complete with a 12 VDC power adapter, and can also provide 12V DC power through its auxiliary 12V DC output terminals.

## **Features**

- Detects ring voltage and loop connect
- Screw terminal connections
- Wall mountable with foam tape (included) or screws (not included)
- Auxiliary 12V DC output
- Adjustable time-out for relay closure
- Two sets of relay contacts provided
- Selectable NO (normally open) or NC (normally closed) relay contacts
- Limited one year warranty

[info@vikingelectronics.com](mailto:info@vikingelectronics.com)

<http://www.vikingelectronics.com>

## **Applications**

- Control a strobe light for ring indication
- Provide relay closures on ring and off-hook
- Trigger a security camera
- Trigger a tape recorder
- Phone "In Use" indicator

**Phone... 715.386.8861**

## **Specifications**

**Power:** 120V AC to 12V DC adapter provided  
**Dimensions:** 74mm x 53mm x 25mm (2.9" x 2.1" x 1.0")  
**Shipping Weight:** 0.4 kg (0.86 lbs)  
**Environmental:** -26° C to 54° C (-15° F to 130° F) with 5% to 95% non-condensing humidity  
**Contact Rating:** .5A @ 125V AC/1A @ 30V DC  
**Maximum Current Draw Auxiliary 12V DC Output:** 350mA  
**Minimum Loop Current:** 15 mA  
**Minimum Ring Voltage:** 40Vrms  
**Ringer Equivalence:** 0.5 A REN  
**Connections:** 10 pin screw terminal block

## IF YOU HAVE A PROBLEM WITH A VIKING PRODUCT, PLEASE CONTACT: VIKING TECHNICAL SUPPORT AT (715) 386-8666

Our Technical Support Department is available for assistance Monday 8am - 4pm, Tuesday to Friday 8am - 5pm central time. So that we can give you better service, before you call please:

1. Know the model number, the serial number and what software version you have (see serial label).
2. Have your Technical Practice in front of you.
3. It is best if you are on site.

### RETURNING PRODUCT FOR REPAIR

The following procedure is for equipment that needs repair:

1. Customer must contact Viking's Technical Support Department at 715-386-8666 to obtain a Return Authorization (RA) number. The customer MUST have a complete description of the problem, with all pertinent information regarding the defect, such as options set, conditions, symptoms, methods to duplicate problem, frequency of failure, etc.
2. Packing: Return equipment in original box or in proper packing so that damage will not occur while in transit. Static sensitive equipment such as a circuit board should be in an anti-static bag, sandwiched between foam and individually boxed. All equipment should be wrapped to avoid packing material lodging in or sticking to the equipment. Include ALL parts of the equipment. C.O.D. or freight collect shipments cannot be accepted. Ship cartons prepaid to:  
**Viking Electronics, 1531 Industrial Street, Hudson, WI 54016**
3. Return shipping address: Be sure to include your return shipping address inside the box. We cannot ship to a PO Box.
4. RA number on carton: In large printing, write the R.A. number on the outside of each carton being returned.

### RETURNING PRODUCT FOR EXCHANGE

The following procedure is for equipment that has failed out-of-box (within 10 days of purchase):

1. Customer must contact Viking's Technical Support at 715-386-8666 to determine possible causes for the problem. The customer MUST be able to step through recommended tests for diagnosis.
2. If the Technical Support Product Specialist determines that the equipment is defective based on the customer's input and troubleshooting, a Return Authorization (R.A.) number will be issued. This number is valid for fourteen (14) calendar days from the date of issue.
3. After obtaining the R.A. number, return the approved equipment to your distributor, referencing the R.A. number. Your distributor will then replace the product over the counter at no charge. The distributor will then return the product to Viking using the same R.A. number.
4. **The distributor will NOT exchange this product without first obtaining the R.A. number from you. If you haven't followed the steps listed in 1, 2 and 3, be aware that you will have to pay a restocking charge.**

### WARRANTY

Viking warrants its products to be free from defects in the workmanship or materials, under normal use and service, for a period of one year from the date of purchase from any authorized Viking distributor or 18 months from the date manufactured, whichever ever is greater. If at any time during the warranty period, the product is deemed defective or malfunctions, return the product to Viking Electronics, Inc., 1531 Industrial Street, Hudson, WI, 54016. Customer must contact Viking's Technical Support Department at 715-386-8666 to obtain a Return Authorization (R.A.) number.

This warranty does not cover any damage to the product due to lightning, over voltage, under voltage, accident, misuse, abuse, negligence or any damage caused by use of the product by the purchaser or others.

Viking's sole responsibility shall be to repair or replace (at Viking's option) the material within the terms stated above. VIKING SHALL NOT BE LIABLE FOR ANY LOSS OR DAMAGE OF ANY KIND INCLUDING INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING DIRECTLY OR INDIRECTLY FROM ANY BREACH OF ANY WARRANTY EXPRESSED OR IMPLIED, OR FOR ANY OTHER FAILURE OF THIS PRODUCT. Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation may not apply to you.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY EXCLUDED BEYOND THE ONE YEAR DURATION OF THIS WARRANTY. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

### FCC REQUIREMENTS

This equipment complies with Part 68 of the FCC rules. Located on the equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN). If requested, this information must be provided to the telephone company.

The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive REN's on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of the REN's should not exceed five (5.0). To be certain of the number of devices that may be connected to the line, as determined by the total REN's, contact the telephone company to determine the maximum REN for the calling area.

This equipment cannot be used on the telephone company-provided coin service. Connection to Party Line Service is subject to State Tariffs.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications in order to maintain uninterrupted service.

If trouble is experienced with this equipment, please contact: **Viking Electronics, Inc., 1531 Industrial Street, Hudson, WI 54016 (715) 386-8666**

If the trouble is causing harm to the telephone network, the telephone company may request you to remove the equipment from the network until the problem is resolved.

The LDB-2 uses the USOC jack RJ11C.

It is recommended that the customer install an AC surge arrester in the AC outlet to which this device is connected. This is to avoid damaging the equipment caused by local lightning strikes and other electrical surges.

This equipment is Hearing-Aid Compatible (HAC).

The telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including fax machines, to send any message unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual. (The telephone number provided may not be a 900 number or any other number for which charges exceed local or long-distance transmission charges.)

### PART 15 LIMITATIONS

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



# Installation

## A. Mounting


The LDB-2 is designed to be wall mounted using the included foam tape or with screws as follows:

|                |  |
|----------------|--|
| <b>Step 1.</b> | Unsnap the plastic cover (see <b>Diagram A</b> ) and remove the top screw holding the circuit board.                                   |
| <b>Step 2.</b> | Loosen the bottom screw and rotate the circuit board to the left, exposing the two mounting holes in the base (see <b>Diagram B</b> ). |
| <b>Step 3.</b> | Screw the base to the wall, etc. using (2) #6 flathead or sheetrock screws.  |

**Note:** Make sure the screw heads are fully driven into the base to avoid shorting the circuit board leads.



## B. Wiring



**IMPORTANT:** Electronic devices are susceptible to lightning and power station electrical surges from both the AC outlet and the telephone line. It is recommended that a surge protector be installed to protect against such surges. Contact Panamax at (800) 472-5555 or Electronic Specialists Inc. at (800) 225-4876.

## C. Ring Detection Only

Connect the incoming line to terminal block positions 1 and 2, as shown in the diagram to the right. No terminal device is required. In this manner, the **LDB-2** can monitor for ringing any place along the ringing line.

## D. Ring and Loop Detection

If the application requires loop as well as ring detection, the **LDB-2** must be placed between the phone line and the terminal device to be monitored. Connect the incoming line to terminal block positions 1 and 2 and connect the terminal device to positions 3 and 4, as shown in the diagram above.


## E. Relay Contacts

Relay contacts are available at terminal block positions 5,6 and 7,8. If the contacts are driving an inductive load, be sure to place a suppression device at the load to snub any high voltage spikes.

## F. Auxiliary 12V DC Output

12V DC is available for low current applications. The positive side is available at terminal position 10, and the negative side is at position 9. Once all the line and load connections have been made, plug in the 120 V AC wall adapter, and replace the cover.



# Programming



## A. Adjustable Relay Closure Time Out

The time out POT (see diagram above) can be adjusted from 2 to 6 seconds. Turn the time out POT counter clockwise to decrease the closure time. Turn it clockwise to increase the closure time. When monitoring for ring, turning the time out POT fully counter clockwise will allow the relay closure to follow standard ring cadence, turning it fully clockwise will allow the relay closure to be maintained during the entire off time of the ring signal. When monitoring for loop, the relay closure will be maintained while off-hook and will time out following an on-hook.

## B. Relay Contact Selections

The relay contacts located at terminal positions 5,6 and 7,8 can be set for normally open (N/O  ) or normally closed (  N/C) by repositioning JP1 and JP2 respectively.

## C. Disabling Ring Detection

If no ring detection is required (loop detection only), clip R2 as show in the diagram on page 3. R2 is a 4.7K ohm resistor that is mounted vertical on the board. (For use with 0.0 REN loading only.)

# Operation

---

## A. Ring Detection Only

With the **LDB-2** in the ring detection mode, incoming ring will activate two relay contacts. The contacts can be independently configured to be either normally open or normally closed. Once ringing is detected it will remain activated for an adjustable time of 2-6 seconds. During the activation time, if ringing stops, the relay will remain activated for the balance of the set time.

## B. Ring and Loop Detection

With the **LDB-2** in the ring and loop detection mode, incoming ring will activate two relay contacts. The contacts can be independently configured to be either normally open or normally closed. Once ringing is detected it will remain activated for an adjustable time of 2-6 seconds. During the activation time, if ringing stops, the relay will remain activated for the balance of the set time. Additionally, the **LDB-2** will detect an off-hook condition. If the device goes off-hook at any time, either with or without ringing, the relay will activate and remain activated for the duration of the off-hook condition.

# Related Products

---

## Affordable ADA Compliant Emergency Phones



The **1600A Series** ADA Compliant Emergency Phones are designed to provide quick and reliable handsfree communication for any standard analog telephone line or analog phone system station port. All **1600A Series** phones meet ADA requirements for elevator/ emergency telephones, and can be programmed from any Touch Tone phone. The phones can dial up to 5 programmable emergency numbers, as well as 2 central station numbers.

The **1600A Series** phones are available in a variety of styles to suit any application. For more information, retrieve **DOD# 215**.

## Surface and Flush Mount Handsfree Doorboxes

Now you can answer your door or gate from the safety of your telephone! The **W-1000** (flush mount) and **W-2000A** (surface mount) doorboxes are designed to be installed on the unused telephone line input of nearly any phone system. One or two doorboxes can also share an existing residential phone line when used in combination with a **C-1000A** doorbox controller.

When the "Call" button is pressed, the doorbox generates a standard ring cadence for an adjustable number of rings. To converse with the visitor, the inside party simply answers the call from the phone of their choice. For more information, retrieve **DOD# 170**.



**Product Support Line...715.386.8666**

**Fax Back Line...715.386.4345**

Due to the dynamic nature of the product design, the information contained in this document is subject to change without notice. Viking Electronics, and its affiliates and/or subsidiaries assume no responsibility for errors and omissions contained in this information. Revisions of this document or new editions of it may be issued to incorporate such changes.